



17. Fuel Pump Relay

A: REMOVAL AND INSTALLATION


- 1) Disconnect battery ground cable.



- 2) Remove lower cover and then disconnect connectors.




- 3) Lower transmission control module.
4) Remove the front pillar lower trim.
<Ref. to 5-3 [W5A1].>
5) Remove fuse box mounting nuts.
6) Lower fuse box.
7) Remove fuse box mounting bracket.
8) Remove fuel pump relay (A) from main relay and fuel pump relay mounting bracket.



- (A) Fuel pump relay
(B) Main relay

- 9) Disconnect connector from fuel pump relay.



- (A) Fuel pump relay
(B) Main relay

- 10) Installation is in the reverse order of removal.