


26. Keyless Entry


A: REMOVAL AND INSTALLATION

1. KEYLESS ENTRY CONTROL MODULE

- 1) Disconnect battery ground cable.
- 2) Remove lower cover and then disconnect connector.



- 3) Remove keyless entry control module (A) while disconnecting connector.



- 4) Installation is in the reverse order of removal.

Tightening torque:

T: 7.4 ± 2.5 N·m (0.75 ± 0.25 kg·m, 5.4 ± 1.8 ft·lb)

MEMO: