


10. Transfer and Extension



B3M0881A

- (1) Thrust needle bearing
- (2) Needle bearing
- (3) Snap ring
- (4) Pressure plate
- (5) Drive plate
- (6) Driven plate
- (7) Snap ring
- (8) Transfer piston seal
- (9) Return spring

- (10) Transfer clutch piston
- (11) Rear drive shaft
- (12) Ball bearing
- (13) Seal ring
- (14) Gasket
- (15) Transfer clutch pipe
- (16) Extension case
- (17) Transmission hanger
- (18) Oil seal

- (19) Dust seal
- (20) Test plug
- (21) O-ring
- (22) Clip

**Tightening torque: N-m (kg-m, ft-lb)**

**T1: 13±1 (1.3±0.1, 9.4±0.7)**

**T2: 25±2 (2.5±0.2, 18.1±1.4)**