



3. Fuel Filler Pipe

A: REMOVAL


- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Open fuel flap lid, and remove fuel filler cap.




- 3) Disconnect battery ground cable.




- 4) Drain fuel from fuel tank. <Ref. to 2-8 [W1C0].>




- 5) Remove screws which install fuel filler pipe on filler lid open.




- 6) Remove wheel nuts of rear right side.
- 7) Lift-up the vehicle.
- 8) Remove rear right side wheel.




- 9) Remove bolts which install protector cover on body.




- 10) While releasing the under side of protector cover from hook, remove it.




- 11) Disconnect evaporation hoses from pipes.




12) Remove bolts which hold fuel filler pipe bracket.



17) Remove fuel filler pipe to under side of vehicle.




13) Lift-up the vehicle more.
14) Remove two evaporation hoses from clip.




B: INSTALLATION


1) Set fuel filler pipe from under side of vehicle, and hold it on fuel filler flap open.




15) Disconnect evaporation hose from joint pipe.



2) Connect fuel filler pipe into fuel filler hose.




16) Loosen clamp, and disconnect fuel filler hose from fuel filler pipe.




2-8 [W3B0]
3. Fuel Filler Pipe

SERVICE PROCEDURE


- 3) Lower the vehicle.
- 4) Temporarily tighten screws which install fuel filler pipe on filler lid open.




- 5) Tighten bolt which holds fuel filler pipe on body.




- 6) Connect evaporation hoses to pipes.




- 7) Lift-up the vehicle.
- 8) Tighten clamp bolt which holds fuel filler hose.




- 9) Install two evaporation hoses to clip.




- 10) Connect evaporation hose to joint pipe.




- 11) Lower the vehicle.
- 12) While holding the under side of protector cover on bracket, install it.




- 13) Tighten bolts which install protector cover on body.




14) Tighten screws which install fuel filler pipe on filler lid open.




15) Install rear right wheel.




16) Install fuel filler cap.




17) Install fuel pump, and connect connector and fuel hoses. <Ref. to 2-8 [W5C0].>



18) Install fuel sub meter unit, and connect connector and jet pump hose. <Ref. to 2-8 [W9A0].>




19) Connect battery ground terminal.




C: DISASSEMBLY


1) Move clip, and disconnect evaporation hose from joint pipe.




2) Remove bolt which installs joint pipe on fuel filler pipe.




3) Disconnect evaporation hose from fuel filler pipe.



4) Disconnect evaporation hoses from shut valve.




5) Remove shut valve from fuel filler pipe.




D: ASSEMBLY

1) Install shut valve on fuel filler pipe.


Tightening torque:
 $4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)




2) Connect evaporation hoses to shut valve.



3) Connect evaporation hose to fuel filler pipe.



4) Connect evaporation hose to evaporation pipe.



5) Install evaporation pipe to fuel filler pipe.

