



2) Release motor harness from shroud.




3) Remove bolts which install fan motor onto shroud.



4) Assembly is in the reverse order of disassembly.

Tightening torque:

$4.4 \pm 0.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.05 \text{ kg}\cdot\text{m}$, $3.3 \pm 0.4 \text{ ft}\cdot\text{lb}$)




8. Water Pipe

A: REMOVAL

1) Release fuel pressure.


<Ref. to 2-8 [W1B0].>

2) Disconnect ground cable from the battery.




3) Drain engine coolant completely.

<Ref. to 2-5 [W1A0].>




4) Remove intake manifold.


<Ref. to 2-7 [W4A0].>




- 5) Disconnect heater inlet hose.



- 6) Disconnect radiator inlet hose from water pipe.



- 7) Remove bolts which install water pipe on cylinder block.



B: INSTALLATION


- 1) Install water pipe on cylinder block.

Tightening torque:


6.4 ± 0.5 N·m (0.65 ± 0.05 kg·m, 4.7 ± 0.4 ft·lb)

CAUTION:

Use a new O-ring.



- 2) Connect radiator inlet hose.



- 3) Connect heater inlet hose.

