


9. Room Light and Door Switch

A: REMOVAL AND INSTALLATION

1. ROOM LIGHT


- 1) Pry room light lens off using a screwdriver.
- 2) Remove screws which secure room light body.



- 3) Remove room light body while disconnecting connector.
- 4) Installation is in the reverse order of removal.

2. TRUNK ROOM LIGHT (SEDAN)

- 1) Turn trunk room light body by hand and remove it from rear shelf panel.
- 2) Disconnect connector of trunk room light.




- 3) Installation is in the reverse order of removal.

3. LUGGAGE ROOM LIGHT (WAGON)

- 1) Pry luggage room light lens off using a screwdriver.
- 2) Remove screws which secure luggage room light body.


- 3) Remove luggage room light body while disconnecting connector.



- 4) Installation is in the reverse order of removal.

4. DOOR SWITCH

- 1) Remove rubber boot of door switch.
- 2) Remove screw which secures door switch to body.



- 3) Remove door switch while disconnecting connector.
- 4) Installation is in the reverse order of removal.

5. TRUNK ROOM LIGHT SWITCH (SEDAN)

Remove and install trunk room light switch which is installed in trunk lid lock. <Ref. to 5-1 [W2A3].>

6. LUGGAGE ROOM LIGHT SWITCH (WAGON)

Remove and install luggage room light switch which is installed in rear gate lock. <Ref. to 5-2 [W3A2].>

B: INSPECTION

1. DOOR SWITCH

Move switch and check continuity between terminal of door switch and switch body.

Switch position	Terminal	Switch body
Open (ON)		
Push in (OFF)		

B6M0835A

2. TRUNK ROOM LIGHT SWITCH (SEDAN)

Move switch and check continuity between terminals of trunk room light switch.

Terminal	1	2
Switch position		
Open (ON)		
Push in (OFF)		

SEDAN

B6M0836A

3. LUGGAGE ROOM LIGHT SWITCH (WAGON)

Move switch and check continuity between terminals of luggage room light switch.

Terminal	1	2
Switch position		
Open (ON)		
Push in (OFF)		

WAGON

B6M0837A