





18. Air Intake Chamber (Except 2200 cc California Spec. Vehicles)

A: REMOVAL AND INSTALLATION

1) Loosen clamps which connect air intake chamber to throttle body and air intake duct.



2) Disconnect air hoses from air intake chamber.

3) Remove bolts which secure air intake chamber to stays.

4) Remove air intake chamber.
5) Installation is in the reverse order of removal.

Tightening torque:
4.9±0.5 N·m (0.5±0.05 kg·m, 3.6±0.4 ft·lb)