


5) Installation is in the reverse order of removal.

Tightening torque:


22.5 ± 7 N·m (2.3 ± 0.7 kg·m, 16.6 ± 5.1 ft·lb)




4. Purge Control Solenoid Valve

A: REMOVAL AND INSTALLATION


1) Disconnect battery ground cable.



2) Remove air cleaner assembly and air intake duct (A) and (B) as a unit. (2200 cc California spec. vehicles) <Ref. to 2-7 [W1A0].>





3) Remove air intake chamber and air intake duct as a unit. (Except 2200 cc California spec. vehicles and 2500 cc Model) <Ref. to 2-7 [W18A0].>





2-1 [W4A0]

SERVICE PROCEDURE

4. Purge Control Solenoid Valve





- 4) Remove bolt which installs purge control solenoid valve to intake manifold.



- 5) Take out purge control solenoid valve.
6) Disconnect connector from purge control solenoid valve.
7) Disconnect vacuum hoses from purge control solenoid valve.

CAUTION:
Carefully connect the evaporation hoses.



- 8) Installation is in the reverse order of removal.

Tightening torque:

15.7 ± 1.5 N·m (1.6 ± 0.15 kg·m, 11.6 ± 1.1 ft·lb)