



## 10. Pressure Control Solenoid Valve

### A: REMOVAL AND INSTALLATION


- 1) Disconnect battery ground cable.




- 2) Remove canister. <Ref. to 2-1 [W3A0].>



- 3) Remove bolt which installs pressure control solenoid valve holding bracket on body.




- 4) Disconnect connector from pressure control solenoid valve.




- 5) Disconnect two evaporation hoses from pressure control solenoid valve.


- 6) Remove pressure control solenoid valve with bracket.



- 7) Remove pressure control solenoid valve from bracket.




- 8) Disconnect vacuum hose from pressure control solenoid valve.



9) Installation is in the reverse order of removal.

**Tightening torque:**

**$24.5 \pm 5$  N·m ( $2.5 \pm 0.5$  kg·m,  $18.1 \pm 3.6$  ft·lb)**




B2M1781

## 11. Vent Control Solenoid Valve (2500 cc Model)

### A: REMOVAL


1) Disconnect battery ground cable.



B2M1723


2) Lift-up the vehicle.

3) Remove canister. <Ref. to 2-1 [W3A0].>



B2M1780

4) Disconnect two hoses from air filter.



B2M1888A