

B: INSTALLATION

Installation is in the reverse order of removal.


1) Connect fuel delivery hose to pipe with an overlap of 20 to 25 mm (0.79 to 0.98 in).

Type A: When fitting length is specified.

Type B: When fitting length is not specified.

ℓ : 1.0 — 4.0 mm (0.039 — 0.157 in)

L: 20 — 25 mm (0.79 — 0.98 in)




- (1) Fitting
- (2) Clamp
- (3) Hose

2) Connect evaporation hose to pipe by approx. 15 mm (0.59 in) from hose end.

L = 15 — 20 mm (0.59 — 0.79 in)

CAUTION:

Be sure to inspect hoses and their connections for any leakage of fuel.




- (1) Hose
- (2) Clip
- (3) Pipe

8. Roll Over Valve

A: REMOVAL AND INSTALLATION

- 1) Lift-up the vehicle.
- 2) Remove roll over valve with bracket.




3) Disconnect hoses from roll over valve, and remove it from bracket.

4) Installation is in the reverse order of removal.


CAUTION:

- Do not install top side of valve down.
- Before installing bracket on body, securely fit concave part of bracket to hole in body.



B: INSPECTION

1) Connect hoses to roll over valve as shown in Figure.




2) While blowing through open end of hose, tilt valve at least 90° left and right from normal position.

3) Ensure that there is no air flow when hose is tilted greater than 90°.

9. Fuel Sub Meter Unit


A: REMOVAL AND INSTALLATION

1) Disconnect battery ground cable.




2) Remove rear seat.

3) Remove service hole cover.



4) Disconnect connector from fuel sub meter, and disconnect jet pump hose.



5) Remove fuel sub meter unit.

