


5. How to Use Super Multiple Junction (S.M.J.)


A: TERMINAL ARRANGEMENT

The "S.M.J." indicated in wiring diagrams is shown in a simplified form.


1. LHD MODEL



2. RHD MODEL



B: INSTALLATION



Tightening torque:

5.9±1.5 N·m (0.6±0.15 kg·cm, 4.3±1.1 in·lb)

NOTE:

- Align the cutout portion of one connector with that of other before tightening the connecting bolt.
- Do not tighten the bolt excessively since this may deform the connectors.

C: EXPLANATION OF S.M.J. SHOWN IN THE WIRING DIAGRAM

