


## 18. Rear Spoiler

### A: REMOVAL AND INSTALLATION


- 1) Open trunk lid.
- 2) Disconnect high-mount stop light connector located inside the trunk lid.
- 3) Remove rubber caps.



- 4) Remove rear spoiler mounting nuts.

#### CAUTION:

When removing nuts, be careful not to drop them inside rear gate.



- 5) Installation is in the reverse order of removal.


#### Tightening torque:

$7.4 \pm 2.0 \text{ N}\cdot\text{m}$  ( $0.75 \pm 0.2 \text{ kg}\cdot\text{m}$ ,  $5.4 \pm 1.4 \text{ ft}\cdot\text{lb}$ )


## 19. Roof Spoiler

### A: REMOVAL AND INSTALLATION

- 1) Open rear gate and remove rear gate trim upper and side.




- 2) Remove high-mount stop light. <Ref. to 6-2 [W6A4].>
- 3) Remove plastic caps and harness covers.



- 4) Remove roof spoiler mounting nuts.

#### CAUTION:

- When removing nuts, be careful not to drop them inside rear gate.
- Be careful since two-sided tape is placed between roof spoiler and body panel.



- 5) Installation is in the reverse order of removal.

#### Tightening torque:

$7.4 \pm 2.0 \text{ N}\cdot\text{m}$  ( $0.75 \pm 0.2 \text{ kg}\cdot\text{m}$ ,  $5.4 \pm 1.4 \text{ ft}\cdot\text{lb}$ )