


15. Engine Control Module


A: REMOVAL AND INSTALLATION

1. 2200 cc MODEL


1) Disconnect battery ground cable.




2) Remove side sill front cover.
<Ref. to 5-3 [W5A1].>




3) Detach floor mat of front passenger seat.




4) Remove protect cover.




5) Remove nuts which hold ECM to bracket.




6) Remove clip from bracket.



7) Disconnect ECM connectors.



8) Take out ECM.



9) Installation is in the reverse order of removal.

CAUTION:
When replacing ECM, be careful not to use the wrong spec. ECM to avoid any damage to the fuel injection system.


2-7 [W15A2]

15. Engine Control Module

SERVICE PROCEDURE


2. 2500 cc MODEL

1) Disconnect battery ground cable.




2) Remove front pillar lower trim.


<Ref. to 5-3 [W5A1].>




3) Detach floor mat of front passenger seat.




4) Remove protect cover.




5) Remove vinyl cover and nuts which hold ECM to bracket.




6) Remove clip from bracket.




7) Remove connector cover.



8) Disconnect ECM connector.



9) Take out ECM.




10) Installation is in the reverse order of removal.


16. Main Relay

A: REMOVAL AND INSTALLATION

1) Disconnect battery ground cable.



2) Remove lower cover and then disconnect connectors.



3) Lower transmission control module.

4) Remove the front pillar lower trim.

<Ref. to 5-3 [W5A1].>

5) Remove fuse box mounting nuts.

6) Lower fuse box.

7) Remove fuse box mounting bracket.

8) Remove screw which retains bracket of main relay and fuel pump relay.

