


## 14. Combination Meter


### A: REMOVAL AND INSTALLATION

#### 1. COMBINATION METER

- 1) Move steering wheel fully down.
- 2) Remove screws which secure meter visor.



- 3) Remove visor from instrument panel.
- 4) Disconnect connectors from meter visor.
- 5) Remove screws which secure combination meter, and pull combination meter out.




- 6) Disconnect connectors from back of combination meter.
- 7) Installation is in the reverse order of removal.

#### CAUTION:

**When installing combination meter, be sure to connect connectors to backside of combination meter.**

**B: BULB REPLACEMENT**



B6M0761C

- |   |                               |  |
|---|-------------------------------|--|
| (1) Tachometer and temperature gauge illumination | (7) Door open (Front-Right)   | (15) Speedometer and fuel gauge illumination |
| (2) Oil pressure                                  | (8) Seat belt                 | (16) Low fuel                                |
| (3) CHECK ENGINE (Malfunction Indicator Light)    | (9) Door open (Front-Left)    | (17) Charge                                  |
| (4) Tachometer illumination                       | (10) Door open (Rear-Right)   | (18) Brake fluid level/parking brake         |
| (5) Turn signal (RH)                              | (11) Door open (Rear-Left)    | (19) FWD                                     |
| (6) Headlight beam                                | (12) Rear gate open (Wagon)   | (20) AT oil temperature                      |
|   | (13) Turn signal (LH)         | (21) ABS                                     |
|   | (14) Speedometer illumination |  |