


10. Camshaft Position Sensor


A: REMOVAL AND INSTALLATION

1. 2200 cc MODEL


- 1) Disconnect battery ground cable.




- 2) Disconnect connector from camshaft position sensor.




- 3) Remove bolt which installs camshaft position sensor to camshaft position sensor support.



- 4) Remove bolt which installs camshaft position sensor support to camshaft cap LH.



- 5) Remove camshaft position sensor and camshaft position sensor support as a unit.
- 6) Remove camshaft position sensor itself.



- 7) Installation is in the reverse order of removal.

Tightening torque:

Camshaft position sensor support;


6.4±0.5 N·m (0.65±0.05 kg·m, 4.7±0.4 ft·lb)

Camshaft position sensor;

6.4±0.5 N·m (0.65±0.05 kg·m, 4.7±0.4 ft·lb)

2. 2500 cc MODEL

- 1) Disconnect battery ground cable.




2-7 [W11A0]


11. Pressure Sensor (AT model)

SERVICE PROCEDURE

- 2) Disconnect connector from camshaft position sensor.



- 3) Remove camshaft position sensor from camshaft support LH.



- 4) Installation is in the reverse order of removal.

Tightening torque:

$6.4 \pm 0.5 \text{ N}\cdot\text{m}$ ($0.65 \pm 0.05 \text{ kg}\cdot\text{m}$, $4.7 \pm 0.4 \text{ ft}\cdot\text{lb}$)

11. Pressure Sensor (AT model)

A: REMOVAL AND INSTALLATION

- 1) Disconnect connector from pressure sensor.
- 2) Disconnect hose from pressure sensor.
- 3) Remove pressure sensor from bracket.
- 4) Installation is in the reverse order of removal.

Tightening torque:

$6.4 \pm 0.5 \text{ N}\cdot\text{m}$ ($0.65 \pm 0.05 \text{ kg}\cdot\text{m}$, $4.7 \pm 0.4 \text{ ft}\cdot\text{lb}$)

