


## 25. Wiper Deicer

### A: REMOVAL AND INSTALLATION

#### 1. WIPER DEICER SWITCH

- 1) Detach console cover while disconnecting connector.
- 2) Remove wiper deicer switch from console cover.




- 3) Installation is in the reverse order of removal.

### B: INSPECTION

#### 1. WIPER DEICER SWITCH

Set switch to each position and check continuity between terminals.



#### 2. WIPER DEICER RELAY

Check continuity between terminals as indicated in table below, when connecting the battery to terminal No. 1 and No. 2.

When current flows.	Between terminals No. 3 and No. 4	Continuity exists.
When current does not flow.	Between terminals No. 3 and No. 4	Continuity does not exist.
	Between terminals No. 1 and No. 2	Continuity exists.

