



7. EGR Solenoid Valve (2500 cc Model)

A: REMOVAL AND INSTALLATION

- 1) Disconnect battery ground cable.




- 2) Remove air intake chamber. <Ref. to 2-7 [W18A0].>




- 3) Disconnect vacuum hoses from EGR solenoid valve.

- 4) Disconnect connector from EGR solenoid valve.



- 5) Remove bolt which installs EGR solenoid valve onto intake manifold.



- 6) Installation is in the reverse order of removal.

Tightening torque:

$15.7 \pm 1.5 \text{ N}\cdot\text{m}$ ($1.6 \pm 0.15 \text{ kg}\cdot\text{m}$, $11.6 \pm 1.1 \text{ ft}\cdot\text{lb}$)