


1. Steering Wheel and Column (Tilt)

A: WITH AIRBAG MODEL



B4M0551B

- | | |
|-----------------------------|--------------------|
| (1) Bushing | (5) Steering wheel |
| (2) Column shaft | (6) Airbag module |
| (3) Steering roll connector | |
| (4) Column cover | |

Tightening torque: N·m (kg·m, ft·lb)

T1: 25±5 (2.5±0.5, 18.1±3.6)

T2: 34±5 (3.5±0.5, 25.3±3.6)