


**2. WAGON FRONT (OUTBACK)**

1) Alignment of height between sunroof panel and roof panel

Loosen sunroof panel installation bolts and nuts then adjust height by adding (Max: two pieces) and extracting (Max: one piece) shim(s) (Standard: one piece) between sunroof panel hinge and body.

**Difference in height between sunroof panel and roof panel:**

**$0 \pm 1.0 \text{ mm } (0 \pm 0.039 \text{ in})$**




2) Alignment of partition clearance

Loosen sunroof panel installation bolts and nuts then move glass to either side to adjust front, rear, right, and left side partitions.

**Partition clearance:**


**$1 \pm 1.0 \text{ mm } (0.04 \pm 0.039 \text{ in})$**



**17. Undercover**

**A: REMOVAL AND INSTALLATION**

1) Remove undercover mounting bolts.



2) Installation is in the reverse order of removal.

**NOTE:**

Undercover is bolted along with mud guard.