



- 5) Connect rear oxygen sensor connector. (Except 2500 cc California spec. vehicles)




- 6) Lower the vehicle.  
7) Connect battery ground cable.




### 3. Canister

#### A: REMOVAL AND INSTALLATION


- 1) Lift-up the vehicle.  
2) Loosen two clamps which hold two canister hoses.



- 3) Disconnect evaporation three hoses from canister.




- 4) Remove canister from body.



5) Installation is in the reverse order of removal.

**Tightening torque:**


**$22.5 \pm 7$  N·m ( $2.3 \pm 0.7$  kg·m,  $16.6 \pm 5.1$  ft·lb)**




## 4. Purge Control Solenoid Valve

### A: REMOVAL AND INSTALLATION

1) Disconnect battery ground cable.



2) Remove air cleaner assembly and air intake duct (A) and (B) as a unit. (2200 cc California spec. vehicles) <Ref. to 2-7 [W1A0].>



3) Remove air intake chamber and air intake duct as a unit. (Except 2200 cc California spec. vehicles and 2500 cc Model) <Ref. to 2-7 [W18A0].>

