


## 10. Spot Light

### A: REMOVAL AND INSTALLATION

#### 1. SPOT LIGHT AND SWITCH

- 1) Pry spot light lens off using a screwdriver.
- 2) Remove screws which secure spot light body.




- 3) Remove spot light body while disconnecting connector(s).
- 4) Installation is in the reverse order of removal.

### B: INSPECTION

#### 1. SPOT LIGHT SWITCH


Move switch and check continuity between terminal of spot light switch connector and steel plate as shown.



## 11. Front Wiper and Washer

### A: ADJUSTMENT


- 1) Turn the wiper switch to OFF position.
- 2) Adjust blades in original position as shown in figure by changing wiper arm installation.



### B: REMOVAL AND INSTALLATION

#### 1. BLADE


- 1) Pull out blade following the arrow direction from arm while pushing up locking clip.



- 2) Installation is in the reverse order of removal.

#### 2. WIPER ARM

- 1) Open front hood.
- 2) Remove cap of wiper arm installation nut.
- 3) Remove the nut which secures wiper arm.



- 4) Remove wiper arm.
- 5) Installation is in the reverse order of removal.