


3. Cylinder Head and Valve Assembly



B2M1955A

- |                              |                           |                                |
|------------------------------|---------------------------|--------------------------------|
| (1) Exhaust valve            | (5) Intake valve oil seal | (9) Exhaust valve guide        |
| (2) Intake valve             | (6) Valve spring          | (10) Exhaust valve spring seat |
| (3) Intake valve guide       | (7) Retainer              | (11) Exhaust valve oil seal    |
| (4) Intake valve spring seat | (8) Retainer key          |                                |